

NASA TECHNICAL MEMORANDUM

NASA TM X-73341

(NASA-TM-X-73341) EVALUATION OF A HIGH
POWER INVERTER FOR POTENTIAL SPACE
APPLICATIONS (NASA) 62 p HC \$4.50 CSCL 09C

N76-33406

Unclass

G3/33 05380


EVALUATION OF A HIGH POWER INVERTER FOR POTENTIAL SPACE APPLICATIONS

By Buddy V. Guynes and John R. Lanier, Jr.
Electronics and Control Laboratory

August 1976

NASA

*George C. Marshall Space Flight Center
Marshall Space Flight Center, Alabama*



1 REPORT NO NASA TM X-73341	2 GOVERNMENT ACCESSION NO	3 RECIPIENT'S CATALOG NO.	
4 TITLE AND SUBTITLE Evaluation of a High Power Inverter for Potential Space Applications		5 REPORT DATE August 1976	
		6 PERFORMING ORGANIZATION CODE	
7 AUTHOR(S) Buddy V. Guynes and John R. Lanier, Jr.		8 PERFORMING ORGANIZATION REPORT #	
9 PERFORMING ORGANIZATION NAME AND ADDRESS George C. Marshall Space Flight Center Marshall Space Flight Center, Alabama 35812		10 WORK UNIT NO.	
		11 CONTRACT OR GRANT NO	
12 SPONSORING AGENCY NAME AND ADDRESS National Aeronautics and Space Administration Washington, D. C. 20546		13 TYPE OF REPORT & PERIOD COVERED Technical Memorandum	
		14 SPONSORING AGENCY CODE	
15 SUPPLEMENTARY NOTES Prepared by Electronics and Control Laboratory, Science and Engineering			
16 ABSTRACT <p>The ADM-006 inverter discussed in this report utilizes a unique method of using power switching circuits to produce three-phase low harmonic content voltages without any significant filtering. This method, developed by Delco Electronics of General Motors Corporation, is referred to as the "Power Center" approach to inverter design and is explained briefly in this report.</p> <p>This report presents the results of tests performed by MSFC to evaluate Delco's claims on inverter performance, especially when required to provide power to nonlinear loads such as half or full wave rectified loads with capacitive filtering. Test procedures and results are described.</p> <p>These tests show that the Power Center inverter essentially met or exceeded all of Delco's claims excluding voltage regulation (3.9 percent versus specified 3.3 percent) and would be a good candidate for high power inverter applications such as may be found on Space Station, Spacelab, etc.</p>			
17 KEY WORDS		18 DISTRIBUTION STATEMENT Unclassified -- Unlimited	
19 SECURITY CLASSIF (of this report) Unclassified	20 SECURITY CLASSIF (of this page) Unclassified	21 NO OF PAGES 63	22 PRICE NTIS

TABLE OF CONTENTS

	Page
INTRODUCTION	1
ADM-006 INVERTER CIRCUIT DESCRIPTION	1
TEST PROCEDURES AND RESULTS	2
Rated Output Power Test	2
Rated Output Voltage Test	3
Power Factor and Waveform Test	3
Low Input Voltage Test	4
Rectifier Load Tests	4
CONCLUSIONS	5
APPENDIX A — ADM-006 SPECIFICATION SHEET	31
APPENDIX B — TEST PROCEDURE 40M22460	33

LIST OF ILLUSTRATIONS

Figure	Title	Page
1.	ADM-006 inverter	15
2.	Laboratory test setup for ADM-006	16
3.	Inverter efficiency as a function of loading	17
4.	Output voltage for Phase A as a function of current for unity power factor load	18
5.	Waveform distortion as a function of resistive loading	19
6.	Inverter efficiency as a function of power factor	20
7.	Total harmonic distortion as a function of power factor.	20
8.	Total harmonic distortion as a function of inductive loading	21
9.	Inverter efficiency as a function of output voltage for constant load impedance	21
10.	Phase A output voltage for 15 kW resistive load	22
11.	Phase A output voltage for 15 kVA inductive load at 0.5 power factor	23
12.	Phase A output voltage for 15 kVA inductive load at 0.9 power factor	24
13.	Phase A output voltage for 15 kVA capacitive load at 0.5 power factor	25
14.	Phase A output voltage for 15 kVA capacitive load at 0.9 power factor	26

LIST OF ILLUSTRATIONS (Concluded)

Figure	Title	Page
15.	Output voltages and phase currents of inverter into pure resistive load half wave rectified	27
16.	Full wave rectified operation without filtering	28
17.	Full wave rectified operation with filtering	29
18.	Full wave rectified operation with RLC load	30

LIST OF TABLES

Table	Title	Page
1.	Rated Output Power Tests	6
2.	Rated Output Voltage Tests	7
3.	Power Factor and Waveform Tests (Inductive Loads) . . .	8
4.	Power Factor and Waveform Tests (Capacitive Loads)	10
5.	Low Input Voltage Tests	12
6.	Rectifier Load Tests	13

DEFINITION OF SYMBOLS

<u>Symbol</u>	<u>Definition</u>
A _{dc}	Amperes direct current
A _{rms}	Amperes root mean square
I	Current
kVA	Kilovolt amperes
kVAR	Kilovolt amperes reactive
kW	Kilowatt
N	Neutral
η	Inverter efficiency
PF	Power factor
V	Voltage
V _{dc}	Voltage direct current
V _{L-N}	Voltage line to neutral
V _{trms}	Voltage true root mean square
THD	Total harmonic distortion

EVALUATION OF A HIGH POWER INVERTER FOR POTENTIAL SPACE APPLICATIONS

INTRODUCTION

The ADM-006 inverter evaluated in this test program (Fig. 1) utilizes a unique method of using power switching circuits to produce three-phase low harmonic content voltages for possible future high power inverter applications such as may be found on Space Station, Spacelab, etc. This method, developed by Delco Electronics Division of General Motors Corporation, is referred to as the "Power Center" approach to inverter design.

The primary purpose of this test program was to evaluate Delco's claims on inverter performance (Appendix A), especially when supplying non-linear or transient loads, and evaluate the inverter as a possible candidate for future high power inverter applications. A secondary benefit of this program was to familiarize MSFC personnel with characteristics of the Power Center approach employed in the ADM-006 inverter.

ADM-006 INVERTER CIRCUIT DESCRIPTION

The complete power circuit for the three-phase inverter consists of left, center, and right circuits, each generating corresponding segments of an approximation of a sine wave without filtering. The inverter consists of a power center which is a three-phase thyristor bridge circuit, a step-former which is a tapped autotransformer with the necessary thyristor and transistor switches for step selection, a diode-thyristor circuit that energizes the autotransformer for "left" and "right" circuit operation, and a set of thyristors called phase selectors that connect the left and right step voltages to the three phase output lines in the proper sequence. The center circuit handles more than 80 percent of the power at approximately 99 percent efficiency. This is the basis for the name

Power Center. The remaining 20 percent of the power passes through the less efficient autotransformer and associated circuitry. This circuitry, although handling only a small portion of the total power, provides a significant contribution to the low distortion sine-wave output.

TEST PROCEDURES AND RESULTS

The ADM-006 inverter was tested in accordance with MSFC test procedure 40M22460 which is included in Appendix B of this report. Procedures are specified in 40M22460 for performing the following tests: (a) rated power output tests, (b) rated output voltage tests, (c) power factor and waveform tests, (d) low input voltage tests, and (e) rectifier load tests.

A photograph of the typical laboratory test setup is presented in Figure 2.

Rated Output Power Tests

The inverter performed satisfactorily when delivering balanced and unbalanced three-phase loads continuous and up to a 28.6 kW load (short term overload rating is 25 kVA) for 1 min. Test results are shown in Table 1. Maximum power delivered to the load was 21.2 kW and not 24 kW as specified in the test procedure. The difference in loading can be attributed to the fact that the load bank used was calibrated to deliver rated power (per switch and vernier control settings) at input voltages of 120 V. However, the inverter was run at loads up to 28.6 kVA (4.62 kW resistive and 8.0 kVAR inductive per phase on load bank dial settings) for periods of approximately 2 min in an unspecified overload test. The inverter automatically shuts itself down when thermal limitations are exceeded, and the inverter did successfully shut down during operation of this overloaded condition.

Inverter efficiency versus resistive and inductive loads are plotted in Figure 3.

Rated Output Voltage Test

These tests were conducted to determine inverter regulation and distortion when operating at rated load. Voltage regulation in percent is defined by

$$\frac{V_{\text{No Load}} - V_{\text{Full Load}}}{V_{\text{Full Load}}} \times 100$$

Using this formula and the data in Table 2, regulation is determined to be 3.9 percent which is slightly higher than the 3.3 percent quoted by Delco. Output voltage is plotted versus load current in Figure 4. Total harmonic distortion was measured and found to be no worse than 3.2 percent for purely resistive three-phase loads (Fig. 5).

Power Factor and Waveform Tests

These tests were performed to determine the inverter's reaction to inductive or capacitive loads of varying power factors. Data from these tests are shown in Tables 3 and 4. Graphical interpretation of the data is shown in Figures 6 through 9. The highest total harmonic distortion measured occurred during inductive loading and was within Delco's specified 4 percent (measured 3.6 percent as shown in Table 3 and Fig. 7). A review of the data supports the claim that the Delco Power Center inverter (ADM-006) is relatively insensitive to capacitive and inductive loads (reactive). Inverter efficiency drops as reactive loading is increased (Figs. 6 and 9). Note also that harmonic distortion increases with increased reactive loading. The increased harmonic content produced by the reactive loading results in increased losses (and decreased efficiency) in the inverter primarily because the power center with just two semiconductor junction voltage drops and a 99 percent efficiency is handling a smaller percentage of the total current. Because of the reactive loads (current lagging or leading voltage), power that was handled by the power center now is channeled through the autotransformer and left or right circuits by the step/phase selectors. Power flowing through this path encounters 11 semiconductor junction voltage drops which is 9 junctions more than encountered when traveling through the power center route. Figures 10 through 14 show inverter waveforms for the different types of loads.

Low Input Voltage Test

A test was conducted to verify that the inverter would operate satisfactorily at input voltages as low as ± 90 Vdc. Data were also taken of input voltages of ± 115 Vdc and the results from both tests are shown in Table 5.

The inverter provided three-phase balanced power of 15 kVA at power factors of 1.0 and 0.6. Data accumulated here and in Table 3 were used to plot the curves shown in Figure 9. Since there is no output voltage regulation on the ADM-006, output voltage phase to neutral varies directly with the input voltage. Hence, inverter efficiency decreases as the output voltage decreases, as shown in Figure 9. The decrease in efficiency can be attributed to the increasing significance of semiconductor junction voltage drops and other constant losses in the inverter as the power being processed is decreased.

Rectifier Load Tests

The purpose of these tests was to determine if the ADM-006 would deliver undistorted power to nonlinear loads such as full or half wave rectified bridges with filter capacitors. Tests were generally performed as indicated in Procedure 40M22460; however, some changes had to be made to preclude blowing fuses in the inverter. The large initial surge of current required to charge the bank of capacitors in the filter would repeatedly blow fuses in the inverter because of the inverters overload current sense and crowbar protection scheme. Therefore, to run these tests, the capacitors first had to be charged up to their ultimate working dc voltage level (V_{out} in Table 6) which was done with an external power supply. This voltage, for the half wave rectified, is approximately 1.4 times the inverter's line to neutral voltage and for the full wave rectified is approximately 1.4 times the inverters line to line voltage. Data for these tests are shown in Table 6. Figures 15 through 18 show inverter output voltage and current wave forms as various nonlinear loads are applied. The ADM-006 can be seen to deliver power to nonlinear loads with very little increased distortion (1 percent higher than the Delco specified 4 percent). A more realistic and less severe test would have been performed with a more typical LC filter. Startup problems would have been eliminated and distortion would have been even less as demonstrated by an unscheduled test.

CONCLUSIONS

These tests show that the ADM-006 Power Center Inverter essentially met or exceeded all of Delco's claims excluding voltage regulation (3.9 versus 3.3 percent) and would be a good candidate for future high power inverter applications such as may be found on Space Station, Spacelab, etc.

Numerous small unexplained problems were encountered during operation of the inverter, i.e., frequent shutdown of the inverter by blown fuses or a tripped circuit breaker. These nuisance shutdowns were attributed to noise in the automatic protection circuits.

Replacement of all integrated circuit devices in these circuits with CMOS or high noise resistant devices would have prevented most, if not all, of the problems encountered during testing. Space applications of this type of inverter should incorporate this change.

ORIGINAL PAGE IS
OF POOR QUALITY

TABLE 1. RATED OUTPUT POWER TESTS

I	II 2 h minimum	III 2 h minimum	IV 1 min	V 1 min
Phase A	5	5	8	8
Phase B	5	5	8	8
Phase C (kW Setting)	5	2	8	4
V_+ to Com	+142	+142	+142	+142
V_- to Com (Vdc)	-142	-142	-142	-142
$I_{IN}(+)$	55.3	+45.3	78.8	65.8
$I_{IN}(-)$ (Adc)	-56.2	-46.2	-79.7	-66.6
V_{A-N}	114.68	114.01	113.47	112.65
V_{B-N}	114.67	114.11	113.21	112.55
V_{C-N} (V rms)	115.14	118.39	113.81	117.88
I_A	43.49	43.12	61.45	60.76
I_B	43.62	43.5	62.09	61.76
I_C	43.5	20.23	63.19	32.86
I_N (A rms)	1.8	23.65	2.06	29.09
Load (Phase A)	4987.4	4916	6973	6845
Load (Phase B)	5001.9	4964	7029	6951
Load (Phase C) (W)	5019.0	2395	7192	3871
Total Load Calculated	15 008	12 275	21 194	17 667

Note: Power Factor = 1.0

TABLE 2. RATED OUTPUT VOLTAGE TESTS

Phase B	0.0 kW	1.5 kW	3.0 kW	4.5 kW	5.0 kW
Balanced 3 Phase Load (kW)	No Load	4.5	9.0	13.5	15.0
V+ to Com	142	142	142	142	142
V- to Com (Vdc)	-142	-142	-142	-142	-142
$I_{IN} (+)$	+1.5	+16.9	31.8	+46.6	51.4
$I_{IN} (-)$ (A dc)	-1.2	-16.5	-31.7	-46.4	-51.3
V_{A-N}	119.3	117.00	116.00	115.1	114.80
V_{B-N}	119.3	116.90	116.00	115.1	114.80
V_{C-N} (V rms)	119.4	117.10	116.20	115.40	115.1
I_A	0	12.07	23.90	35.48	39.28
I_B	0	12.11	24.00	35.73	39.58
I_C	0	12.28	24.26	36.14	40.04
I_N (A rms)	0	0.50	0.945	1.33	1.46
Total Power Calculated (kW)	0	4.26	8.4	12.4	13.7
THD (%)	3.2	2.71	2.4	2.18	2.14

Note: Power Factor = 1.0

TABLE 3. POWER FACTOR AND WAVEFORM TESTS (INDUCTIVE LOADS)

Resistive (kW) per Phase	2.5	3.0	3.5	4.0	4.5	5.0
Inductive (kVAR) per Phase	4.33	4.0	3.57	3.00	2.18	0
Balanced (kVA) 3 Phase Load	15	15	15	15	15	15
Power Factor	0.5	0.6	0.7	0.8	0.9	1.0
V+ to Common	147	147.3	147.4	148.1	148.3	148
V- to Common	147	147.3	147.7	148.1	148.3	148
$I_{IN} (+)$	32.2	35.8	40	44.4	48.8	53.4
$I_{IN} (-)$ (Adc)	33.7	39.2	43.8	47.9	51.8	54.8
I_A (A rms)	41.8	42.1	42.1	42.0	41.7	40.9
I_B (A rms)	42.5	42.9	42.7	42.6	42.1	41.2
I_C (A rms)	43.0	43.3	43.3	43.2	42.8	41.9
I_N (A rms)	0.85	1.16	1.25	1.33	1.30	1.45

TABLE 3. (Concluded)

V_{A-N} (V rms)	119.8	119.9	120	120	119.9	120.1
V_{B-N} (V rms)	120.0	120.0	120.1	120.1	119.9	120.1
V_{C-N} (V rms)	120.1	120.2	120.4	120.3	120.2	120.4
THD (%)	3.6	3.6	3.5	3.35	3.2	2.52

TABLE 4. POWER FACTOR AND WAVEFORM TESTS (CAPACITIVE LOADS)

Resistive (kW) per Phase Setting	0.58	0.75	0.98	1.33	2.06	5.0
Capacitive Load (kVAR) per Phase Setting	1.0	1.0	1.0	1.0	1.0	0
Balanced 3 Phase Load Setting (kVA)	3.46	3.75	4.2	5.0	6.88	15
Power Factor	0.5	0.6	0.7	0.8	0.9	1.0
V_{L-N} (V trms)	120	120	120	120	120	120
V+ to Common (Vdc)	142	142.4	142.6	143.1	144.5	148
V- to Common (Vdc)	142	142.3	142.7	143.1	144.5	148
I_{IN} (+) (Adc)	7.8	9.3	11.4	15.1	23.2	53
I_{IN} (-) (Adc)	8.6	10.2	12.7	16.5	24.1	53.7

TABLE 4. (Concluded)

V_{A-N} (V rms)	120	120	120	120	120	120
V_{B-N} (V rms)	119.9	120	120	119.9	120	120
V_{C-N} (V rms)	120	120	120.1	120	120.1	120.3
I_A (A rms)	9.95	10.56	11.64	13.8	19.16	41.06
I_B (A rms)	10.06	10.66	11.68	13.86	19.33	41.4
I_C (A rms)	10.2	10.8	11.82	14.03	19.54	41.96
I_N (A rms)	0.73	0.73	1.08	1.26	0.94	1.44
THD (%)	3.2	3.23	3.2	3.1	2.71	2.39

TABLE 5. LOW INPUT VOLTAGE TESTS

Input Voltage	± 115 Vdc		± 90 Vdc	
Power Factor	1.0	0.6	1.0	0.6
Balanced 3 Phase Load (kVA)	15	15	15	15
V+ to Com (Vdc)	115.0	115.0	90.0	90.0
V- to Com (Vdc)	115.0	115.0	90.0	90.0
V_{AN} (V rms)	92.6	93.2	71.8	72.7
V_{BN} (V rms)	92.6	93.4	71.8	72.8
V_{CN} (V rms)	92.8	93.5	71.9	72.9
I_+ (Adc)	41.1	27.9	31.8	21.8
I_- (Adc)	42.1	30.8	32.4	24.5
I_A (A rms)	31.5	32.8	24.3	25.6
I_B (A rms)	31.7	33.4	24.5	26.1
I_C/I_N (A rms)	32.2/1.13	33.8/0.85	24.9/0.92	26.4/0.62
THD (%)	2.5	3.7	2.65	3.9


TABLE 6. RECTIFIER LOAD TESTS

	Half Wave			Full Wave		
	No. Transf.	With Transf.		R	RC	RLC
		SI Open	SI Closed			
V+ (Vdc)	142	142	144.6	142	142.4	142.1
V- (Vdc)	142	142	144.5	142	142.2	142.1
I+ (A dc)	17.8	20.9	18.7	15.6	15.4	15.7
I- (A dc)	4.3	3.5	3.7	15	15.9	14.9
I _A (A rms)	13.2	14.8	13.4	11.4	12.85	11.4
I _B (A rms)	13.2	14.8	13.7	11.4	13.01	11.4
I _C (A rms)	13.5	14.8	13.6	11.6	13.34	11.6
I _N (A rms)	17.3		17.5			
I _{out} (A dc)	16.3	15.5	15.9	14.2	15.4	13.8
V _{out} (V dc)	152.5	150.1	152.5	271.2	273	271
Output (V _{pp}) Ripple	3.5	3	3.5	40	0.6	0.5 ^a
V _{A-N} (V trms)	118.1	117.9	120.1	117.7	118.6	117.7

TABLE 6. (Concluded)

	Half Wave			Full Wave		
	No. Transf.	With Transf.		R	RC	RLC
		Sl Open	Sl Closed			
V_{B-N} (V trms)	118.1	117.9	120	117.6	118.6	117.6
V_{C-N} (V trms)	118.1	118	120.2	117.8	118.7	117.8
THD (%)	4.95	5	4.98	3.65	4.8	3.88
Load Setting (kW)	2	2	2	4	4	4
Load Calculated (kW)	2.49	2.33	3.42	3.85	4.2	3.74

a. Ripple measured before L and C was 38 V_{pp}.



ORIGINAL PAGE IS
OF POOR QUALITY

Figure 1. ADM-006 inverter.




Figure 2. Laboratory test setup for ADM-006.




Figure 4. Output voltage for Phase A as a function of current for unity power factor load.




Figure 5. Waveform distortion as a function of resistive loading.




Figure 6. Inverter efficiency as a function of power factor.




Figure 7. Total harmonic distortion as a function of power factor.




Figure 8. Total harmonic distortion as a function of inductive loading.






Figure 9. Inverter efficiency as a function of output voltage for constant load impedance.



100 V/cm

0.5 ms/cm




0.2 ms/cm

Figure 10. Phase A output voltage for 15 kW resistive load.



0.5 ms/cm


100 V/cm



0.2 ms/cm


Figure 11. Phase A output voltage for 15 kVA inductive load at 0.5 power factor.

ORIGINAL PAGE IS
OF POOR QUALITY




0.5 ms/cm

100 V/cm




0.2 ms/cm

Figure 12. Phase A output voltage for 15 kVA inductive load at 0.9 power factor.



0.5 ms/cm


100 V/cm



0.2 ms/cm


Figure 13. Phase A output voltage for 15 kVA capacitive load at 0.5 power factor.

ORIGINAL PAGE IS
OF POOR QUALITY






0.5 ms/cm

100 V/cm



0.2 ms/cm

Figure 14. Phase A output voltage for 15 kVA capacitive load at 0.9 power factor.



**NEUTRAL
CURRENT**





Figure 15. Output voltages and phase currents of inverter into pure resistive load half wave rectified.

ORIGINAL PAGE IS
OF POOR QUALITY

4 kW PURE RESISTIVE


INVERTER
OUTPUT
VOLTAGE

PHASE C
CURRENT



RECTIFIED
OUTPUT
VOLTAGE

PHASE
CURRENT



40 V_{pk-pk}
RIPPLE

Figure 16. Full wave rectified operation without filtering.

4 kW RESISTIVE LOAD





Figure 17. Full wave rectified operation with filtering.

ORIGINAL PAGE IS
OF POOR QUALITY

4 kW RLC LOAD





Figure 18. Full wave rectified operation with RLC load.

DELCO ELECTRONICS
MODEL ADM-006 INVERTER
SPECIFICATION

Characteristics and Performance

Required Input.	± 142 V dc (high power source) 120 V ac, 60 Hz (less than 300 mW for low power control electronics)		
Output (120/208 400 Hz):	Balanced Load	Maximum Load per Phase	Maximum Load Unbalance per Phase
Continuous	15 KVA	5.0 KVA	3 KVA
Intermittent	25 KVA	8.3 KVA	4 KVA
Load Power Factor:	Unity to Zero, leading or lagging		
Voltage Regulation: (open loop)	3.3%		
Distortion:	4% THD		
Ambient Air Temperature:	10 ⁰ C to 50 ⁰ C forced air cooled		
Size.	19"W, 28"H, 29-1/2" D (Enclosed rack cabinet)		
Weight:	Cabinet	100 lbs.	
	Inverter & Breadboard Structure	125 lbs.	
	Total	225 lbs.	
Efficiency:	94%		

APPENDIX B

TEST PROCEDURE 40M22460

NOTICE—When Government drawings, specifications or other data are used for any purpose other than in connection with a definitely related Government procurement operation, the United States Government thereby incurs no responsibility nor obligation whatsoever, and the fact that the Government may have formulated, furnished or in any way supplied the said drawings, specifications or other data is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation or conveying any rights or permission to manufacture, use or sell any patented invention that may in any way be related thereto.

APPLICATION		PART No	MF	REVISIONS		
NEXT ASSY	USED ON			SYM	DESCRIPTION	DATE

TEST PROCEDURE
POWER CENTER INVERTER
(ADM-006)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON: FRACTIONS DECIMALS ANGLES	ORIGINAL DATE OF DRAWING 2/15/75	TEST PROCEDURE POWER CENTER INVERTER (ADM-006)		GEORGE C MARSHALL SPACE FLIGHT CENTER NATIONAL AERONAUTICS AND SPACE ADMINISTRATION HUNTSVILLE ALABAMA	
	DRAFTSMAN				
MATERIAL	TRACER	CHECKER	DWG SIZE A		
	ENGINEER G V.	ENGINEER			
HEAT TREATMENT	SUBMITTED <i>Buddy V. Luperus</i>	40M22460			
FINAL PROTECTIVE FINISH	APPROVED <i>H. Lander</i>				
SCALE		SHEET 1 OF 22			
UNIT WT					

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

1. PURPOSE

1.1 The purpose of this test procedure is to specify the test methods for the verification testing of the Power Center Inverter (ADM-006) built by Delco Electronics Division, General Motors Corporation under Contract NAS8-28645

2. SCOPE

2.1 This procedure specifies the methods for testing the ADM-006 under simulated loading conditions similar to those which might be expected during normal use. Methods for performing the following tests are specified herein

- (a) rated power output tests
- (b) rated output voltage tests
- (c) power factor and waveform tests
- (d) low input voltage tests
- (e) rectifier load tests.

3. REFERENCES

3.1 The following documents form a part of this test procedure to the extent specified herein Unless otherwise indicated, the issue in effect on the date of invitation for bids or request for proposals shall apply.

STANDARDS

MIL-STD-831

Test Reports, Preparation of

DRAWINGS

George C Marshall Space Flight Center

TBD

(Copies of specifications, standards, drawings, and publications required by contractors in connection with the application of this procedure should be obtained from the procuring activity or as directed by the contracting officer.)

4. ABBREVIATIONS

Not applicable

5. RESPONSIBILITIES

5.1 Electronics and Control Laboratory - The Power Branch (EC12) or their representative shall be responsible for the implementation of this procedure.

CODE IDENT NO	DWG SIZE A	40M22460
		SHEET 2

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

6. PROCEDURES

6.1 Test Setup6.1.1 Source Voltage Setup

- (a) Connect four HP6475A power supplies to ADM-006 as specified in figure 1.
- (b) Set all ON-OFF breakers on power supplies to OFF

6.1.2 ADM-006 Setup

- (a) Set INPUT BREAKER to OFF
- (b) Set AUXILIARY 60 Hz switch to OFF
- (c) Set INPUT CONTACTOR switch to OFF
- (d) Set OUTPUT CONTACTOR switch to OFF
- (e) Connect ADM-006 to 120 VAC/60 Hz power

6.1.3 Avtron Model T938 Load Bank Setup for 400 Hz Operation

- (a) Set all KW and KVAR dials to indicate zero.
- (b) Set COOLING AIR BLOWER switch to START. The "Cooling Air Blower" lamp, "Cooling Air Failure" Lamp, the cooling alarm, and the "Air Failure Time Delay" will come on momentarily. When sufficient cooling air is being supplied by the fan, the three air failure indicators will turn off and the "Cooling Air Blower" lamp will remain lit.
- (c) Set the AIR FAILURE TIME DELAY to desired delay. This can be set between zero and five minutes.
- (d) Set the MASTER LOAD switch to OFF
- (e) Set the individual phase switches, PHASE A, PHASE B, and PHASE C, to ON
- (f) Set MODE switch to BALANCED 3 PHASE. In this position real loading and reactive loading is applied to all three phases by adjusting the control switches for KW and KVAR respectively under PHASE B to the desired value.
- (g) Set the COOLING SYSTEM PROTECTION switch to ON.
- (h) Set the LOW FREQUENCY PROTECTION switch to ON.

CODE
IDENT NODWG
SIZE

40M22460

A

SHEET 3

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

6.1.3 Avtron Model T938 Load Bank Setup (Cont'd)

- (i) Set the FREQUENCY switch to 400 Hz.
- (j) Set heater switch to ON.
- (k) Set the Vernier INHIBIT Switch to OFF.

6.1.4 Test Connections

- (a) Connect inverter to load bank as specified in figure 1.
- (b) Connect a DVM (Fairchild 7050 or equivalent) between V+ and common as specified in figure 1.
- (c) Connect a DVM (Fairchild 7050 or equivalent) between V- and common as specified in figure 1.
- (d) Connect a distortion analyzer (Hewlett Packard Model 302A or equivalent), as specified in figure 1.
- (e) Connect a voltmeter (Fluke 9500A or equivalent) from PHASES A, B, and C to Neutral as indicated in figure 1.

6.1.5 Test Equipment6.1.5.1 Instruments

Digital Voltmeter, Fairchild 7050, 2 Ea.

Voltmeter, true RMS, Fluke 9500A

Distortion Analyzer, HP331A

6.1.5.2 Components

Diode, IN 1189, 6 Ea.

Capacitor, 480 u f, 125 V, 36 Ea.

Resistor 604K, 3 Ea.

Auto transformer, variable, 3 phase, 400 Hz, General Radio Co.,
Model M20G3

CODE IDENT NO	DWG SIZE A	40M22460
		SHEET 4

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

6 2 Rated Power Output Tests

- (a) Set the Resistive KW Phase B control switch on the load bank to 5 0 KW This automatically sets phases A and C to 5 0 KW
- (b) Set the AUXILIARY 60 Hz switch on the ADM-006 to ON
- (c) Set the ON-OFF breakers on the HP6475A power supplies to ON
- (d) Adjust supplies for V+ of +142Vdc and V- of -142 Vdc as indicated on the two test meters
- (e) Set the INPUT BREAKER on the ADM-006 to ON
- (f) Set the INPUT CONTACTOR on the ADM-006 to ON
- (g) Set OUTPUT CONTACTOR to ON
- (h) Set the MASTER LOAD switch on the load bank to ON
- (i) Monitor operation for a minimum of two hours as test for continuous rating
- (j) Fill in values in Column II of Table I
- (k) At completion of continuous balanced rating test, set MASTER LOAD switch on the load bank to OFF and the OUTPUT CONTACTOR on the ADM-006 to OFF
- (l) Set MODE switch on the load bank to IND PHASE In this position loading of each phase is controlled by adjusting the individual control switches
- (m) Set Resistive KW PHASE A and PHASE B to 5 0 KW and PHASE C to 2 0 KW
- (n) Repeat steps (g) through (i)
- (o) Fill in values in Column III of Table I
- (p) At the completion of continuous unbalanced rating test, set the MASTER LOAD switch on the load bank to OFF and the OUTPUT CONTACTOR on the ADM-006 to OFF
- (q) Set MODE switch on load bank to BAL 3 PHASE and set RESISTIVE KW PHASE B to 8 0 KW This automatically sets Phases A and C to 8 0 KW
- (r) Set OUTPUT CONTACTOR on ADM-006 to ON and MASTER LOAD switch on load bank to ON

CODE
IDENT NODWG
SIZE

40M22460

A

SHEET 5

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

6.2 Rated Power Output Tests (Cont'd)

- (s) Monitor operation for one minute as test for intermittent rating
Fill in the values in column IV of Table I
- (t) At the completion of the balanced intermittent test set the MASTER LOAD switch on the load bank to OFF and the OUTPUT CONTACTOR on ADM-006 to OFF. Failure to disconnect the load after intermittent test may result in damage to the inverter
- (u) Set MODE switch on load bank to IND PHASE, and set RESISTIVE KW PHASE A and PHASE B to 8 0 KW and PHASE C to 4 0 KW
- (v) Set OUTPUT CONTACTOR on ADM-006 to ON and MASTER LOAD switch on load bank to ON
- (w) Monitor operation for one minute as test for intermittent rating
Fill in the values in Column V of Table I
- (x) Set MASTER LOAD switch on load bank to OFF and OUTPUT CONTACTOR on ADM-006 to OFF. Failure to disconnect the load after intermittent test may result in damage to the inverter

6.3 Rated Output Voltage Tests

- (a) Set MODE switch on load bank to BAL 3 PHASE
- (b) Set RESISTIVE KW PHASE B to zero KW. This automatically sets Phases A and C to zero KW
- (c) Set OUTPUT CONTACTOR on ADM-006 to ON
- (d) Set MASTER LOAD switch on load bank to ON
- (e) Measure and record the values indicated in Table II
- (f) Set MASTER LOAD switch on load bank to OFF
- (g) Set OUTPUT CONTACTOR on ADM-006 to OFF
- (h) Repeat steps (c) through (g) with RESISTIVE KW PHASE B set to each of the values specified in Table II. Phases A and C are set automatically to the value of Phase B
- (i) Determine voltage regulation. Voltage regulation no load to full load shall be less than 4.5 percent

6.4 Power Factor and Waveform Tests6.4.1 Inductive Loading

- (a) Set MODE switch on load bank to BAL 3 PHASE

CODE IDENT NO	DWG SIZE	40M22460
	A	SHEET 6

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

6.4.1 Inductive Loading (Cont'd)

- (b) Set the REACTIVE LOAD switch to INDUCTIVE.
- (c) Set RESISTIVE KW PHASE B to 4.62 KW This automatically sets Phases A and C to 4.62 KW
- (d) Set INDUCTIVE KVAR PHASE B to 8.0 KVAR This automatically sets Phases A and C to 8.0 KVAR
- (e) Set OUTPUT CONTACTOR on ADM-006 to ON
- (f) Set MASTER LOAD switch on load bank to ON
- (g) Measure and record the values indicated in Table III for a power factor of 0.5 Total harmonic distortion shall not be greater than 4.0 percent
- (h) Set MASTER LOAD switch on load bank to OFF
- (i) Set OUTPUT CONTACTOR on ADM-006 to OFF
- (j) Repeat steps (d) through (i) with RESISTIVE KW PHASE B and INDUCTIVE KVAR PHASE B adjusted to each of the values indicated in Table III Phases A and C will be set automatically to the same value as Phase B as long as the Mode switch is in the BAL 3 PHASE position

6.4.2 Capacitive Loading

- (a) Set REACTIVE LOAD switch on load bank to CAPACITIVE
- (b) Set MODE switch to BAL 3 PHASE.
- (c) Set RESISTIVE KW PHASE B to 0.58 KW This automatically sets Phases A and C to 0.58 KW
- (d) Set CAPACITIVE KVAR PHASE B to 1.0 KVAR This automatically sets Phases A and C to 1.0 KVAR
- (e) Set OUTPUT CONTACTOR on ADM-006 to ON
- (f) Set MASTER LOAD switch on load bank to ON
- (g) Measure and record the values indicated in Table IV for a power factor of 0.5 Total harmonic distortion shall not exceed 4.0 percent.
- (h) Set MASTER LOAD switch on load bank to OFF
- (i) Set OUTPUT CONTACTOR on ADM-006 to OFF

CODE IDENT NO	DWG SIZE	40M22460
	A	SHEET 7

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVAL
<p>6 4 2 <u>Capacitive Loading (Cont'd)</u></p> <p>(j) Repeat steps (e) through (j) with RESISTIVE KW PHASE B and CAPACITIVE KVAR PHASE B adjusted to each of the values indicated in Table IV. Phases A and C will be set automatically to the same value as Phase B as long as the MODE switch is in the BAL 3 PHASE position.</p>			
<p>6 5 <u>Low Input Voltage Tests</u></p> <p>(a) Adjust the output controls of the HP6475A power supplies to obtain a balanced input of ± 115 Vdc to the ADM-006</p> <p>(b) Set the mode switch on load bank to BAL 3 PHASE</p> <p>(c) Set all inductive and capacitive KVAR controls to zero</p> <p>(d) Set RESISTIVE KW PHASE B to 5 0 KW. This automatically sets Phases A and C to 5 0 KW.</p> <p>(e) Set the OUTPUT CONTACTOR on ADM-006 to ON</p> <p>(f) Set the MASTER LOAD switch on the load bank to ON</p> <p>(g) Measure and record the values indicated in Table V for the indicated input voltage and a power factor of 1 0</p> <p>(h) Set MASTER LOAD switch on load bank to OFF</p> <p>(i) Set the OUTPUT CONTACTOR on ADM-006 to OFF</p> <p>(j) Set the REACTIVE LOAD switch to INDUCTIVE</p> <p>(k) Set INDUCTIVE KVAR PHASE B to 6 67 KVAR. This automatically sets phases A and C to 6 67 KVAR</p> <p>(l) Set the OUTPUT CONTACTOR on ADM-006 to ON</p> <p>(m) Set the MASTER LOAD switch on load bank to ON</p> <p>(n) Measure and record the values indicated in TABLE V for the indicated input voltage and a power factor of 0 6</p> <p>(o) Set MASTER LOAD switch on load bank to OFF</p> <p>(p) Set the OUTPUT CONTACTOR on ADM-006 to OFF</p> <p>(q) Repeat steps (b) through (p) for an input of ± 90 Vdc to the ADM-006</p> <p>(r) Readjust power supplies for ± 142 Vdc input to ADM-006</p>			
CODE IDENT NO		DWG SIZE A	40M22460 SHEET 8

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

6.6 Rectified Output Test6.6.1 Avtron Model T938 Load Bank Setup for DC OperationCAUTION:

All autotransformers (verniers) located on the Load Bank Control Panel must be disabled before applying DC voltage to the load bank. The VERNIER INHIBIT Switch disables the Resistive Verniers and must be ON during test. The REACTIVE LOAD Switch disables the Inductive and the capacitive Verniers and must be in the OFF position during test. Failure to observe this caution will result in permanent damage to the autotransformers.

- (a) Set MASTER LOAD Switch to OFF.
- (b) Set VERNIER INHIBIT Switch to ON.
- (c) Set REACTIVE LOAD Switch to OFF.
- (d) Set all KW and KVAR dials to indicate ZERO.
- (e) Set COOLING AIR BLOWER Switch to START.
- (f) Set COOLING SYSTEM PROTECTION switch to ON.
- (g) Set AIR FAILURE TIME DELAY to three (3) minutes.
- (h) Set individual phase switches, PHASE A, PHASE B, and PHASE C to ON.
- (i) Set MODE switch to BALANCED 3 PHASE.

CAUTION. Maintain MODE switch in BALANCED 3 PHASE position. With mode switch in individual phase position, unbalanced loading is possible which could result in excessive current in relay contacts in the load bank.

- (j) Set LOW FREQUENCY PROTECTION switch to BYPASS.
- (k) Set HEATER switch to ON.

6.6.2 Half-Wave Rectifier

- (a) Set up test equipment in accordance with figure 2. The filter used shall be as shown in figure 5.
- (b) Set the AUXILIARY 60 HZ switch on the ADM-006 to ON.
- (c) Set the input voltage to the ADM-006 to ± 142 Vdc.

CODE IDENT NO	DWG SIZE	40M22460
	A	SHEET 9

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

- (d) Set the INPUT BREAKER on the ADM-006 to ON.
- (e) Set the INPUT CONTACTOR on the ADM-006 to ON.
- (f) Set the OUTPUT CONTACTOR on the ADM-006 to ON.
- (g) Set the RESISTIVE KW PHASE B selector on the load bank control panel to 2 DC (special marking).
- (h) Set the MASTER LOAD switch on the load bank control panel to ON.
- (i) Measure and record the values indicated in Table VI in the half-wave column.
- (j) Set the MASTER LOAD switch to OFF.
- (k) Set the OUTPUT CONTACTOR TO OFF.

6.6.3 Full-Wave Rectifier

- (a) Set up test equipment in accordance with figure 3. The filter used shall be as shown in figure 5.
- (b) Set the OUTPUT CONTACTOR on the ADM-006 to ON.
- (c) Set the RESISTIVE KW PHASE B selector on the load bank control panel to 4 DC (special marking).
- (d) Set the MASTER LOAD switch on the load bank control panel to ON.
- (e) Measure and record the values indicated in table VI in the full-wave column.
- (f) Set the MASTER LOAD switch to OFF.
- (g) Set the OUTPUT CONTACTOR to OFF.

6.6.4 Transformer Rectifier Loads

- (a) Set up test equipment in accordance with figure 4. The filter used shall be as shown in figure 5.
- (b) Set the OUTPUT CONTACTOR on the ADM-006 to ON.
- (c) Adjust the Variac to obtain an output voltage of (TBD) Vdc.
- (d) Set the RESISTIVE KW PHASE B selector on the load bank control panel to 2 DC (special marking).

CODE IDENT NO	DWG SIZE	40M22460
	A	SHEET 10

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

- (e) Set the MASTER LOAD switch on the load bank control panel to ON.
- (f) Measure and record the values indicated in table VI in the transformer-rectifier column.
- (g) Set the MASTER LOAD switch to OFF.
- (h) Set the OUTPUT CONTACTOR to OFF.
- (i) Remove all power to the system.

7. REPORTS

7.1 At the completion of the verification tests, a test report shall be prepared in accordance with Standard MIL-STD-831. The report shall include all test data and results. A reproducible copy of all data sheets shall be supplied to the procuring activity.

8. MODIFICATIONS OR CHANGES

8.1 Recommendations for modifications or changes to the procedures specified herein shall be submitted in writing to the Chief, Power Branch (EC12), Marshall Space Flight Center, Alabama 35812.

Custodian:

EC12
NASA/George C. Marshall
Space Flight Center

Preparing Activity:

EC12
George C. Marshall
Space Flight Center

CODE IDENT NO	DWG SIZE	40M22460
	A	SHEET 11

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVAL




Figure 1 Test Connections

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVAL





FIGURE 2. HALF-WAVE RECTIFIER

CODE IDENT NO	DWG SIZE
A	40M22460
SHEET 13	

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVAL




NOTE: NC = NO CONNECTION

FIGURE 3. FULL-WAVE RECTIFIER

ORIGINAL PAGE IS
OF POOR QUALITY

CODE IDENT NO	DWG SIZE
A	40M22460
SHEET 14	

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVAL




NOTE: NC = NO CONNECTION

FIGURE 4. TRANSFORMER RECTIFIER

CODE IDENT NO	DWG SIZE	SHEET
A	40M22460	15

REVISIONS			
SYM	DESCRIPTION	DATE	APPROVAL



Note All capacitors will be 480 f, 125 V

Figure 5 Filter for rectifier load tests

CODE IDENT NO	DWG SIZE
A	40M22460
SHEET 16	

REVISIONS

SYM

DESCRIPTION

DATE

APPROVAL

Table I Rated Output Power Tests.

I	II	III	IV	V
Phase A	5 KW	5 KW	8 KW	8 KW
Phase B	5 KW	5 KW	8 KW	8 KW
Phase C	5 KW	5 KW	8 KW	4 KW
(nominal)				
V ₊ to Com	+ 142 VDC	+ 142 VDC	+ 142 VDC	+ 142 VDC
V ₋ to Com	- 142 VDC	- 142 VDC	- 142 VDC	- 142 VDC
(nominal)				
V _{A-N} , V _{B-N} , V _{C-N}	120 V	120 V	120 V	120 V
(nominal)	RMS	RMS	RMS	RMS
V ₊ to Com				
V ₋ to Com				
(measured) I^+ / I^-	/	/	/	/
V _{A-N}				
V _{B-N}				
V _{C-N}				
(measured)				
I _A				
I _B				
I _C				
(measured)				
Load (Phase A)				
Load (Phase B)				
Load (Phase C)				
(measured)				
Total Load				
(measured)				

Note PF = 1.0

CODE
IDENT NODWG
SIZE

40M22460

A

SHEET 17

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

Table II Rated Output Voltage Tests.

Phase B	0 0 KW	1.5 KW	3 KW	4.5 KW	5 0 KW
Balanced 3 ϕ Load	No Load	4.5 KW	9 0KW	13 5 KW	15-0KW
V ₊ to Com	+ 142 VDC	+ 142 VDC	+ 142 VDC	+ 142 VDC	+ 142 VDC
V ₋ to Com	- 142 VDC	- 142 VDC	- 142 VDC	- 142 VDC	- 142 VDC
(nominal)					
V _{AN} , V _{BN} , V _{CN} (nominal)	120 V RMS	120 V RMS	120 V RMS	120 V RMS	120 V RMS
V ₊ to Com					
V ₋ to Com					
(measured)					
I ₊ (measured) I ₋					
V _{A-N}					
V _{B-N}					
V _{C-N} (measured)					
I _A					
I _B					
I _C (measured) I _N					
THD					

Note PF = 1.0

$$\text{Regulation (\%)} = 100 \times \frac{V_{NL} - V_{FL}}{V_{FL}} =$$

CODE IDENT NO	DWG SIZE	40M22460
	A	SHEET 18

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

Table III. Power Factor and Waveform Tests (Inductive Loads).

Resistive KW Per Phase	2.5 KW	3.0 KW	3.5 KW	4.0 KW	4.5 KW	5.0 KW
Inductive KVAR Per Phase	4.33 KVAR	4.0 KVAR	3.57 KVAR	3.00 KVAR	2.18 KVAR	0 KVAR
Balanced 3Ø Load	15 KVA	15 KVA	15 KVA	15 KVA	15 KVA	15 KVA
Power Factor	0.5	0.6	0.7	0.8	0.9	1.0
V _{L-N} (nominal)	120 VRMS	120 VRMS	120 VRMS	120 VRMS	120 VRMS	120 VRMS
V+ to Common						
V- to Common						
I+ / I-	/	/	/	/	/	/
I _A / I _B / I _C	/ /	/ /	/ /	/ /	/ /	/ /
V _{A-N}						
V _{B-N}						
V _{C-N}						
THD						

Note Total harmonic distortion shall be less than 4%

CODE IDENT NO	DWG SIZE A	40M22460
		SHEET 19

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

Table IV. Power Factor and Waveform Tests (Capacitive Loads).

Resistive KW	.58 KW	.75 KW	.98 KW	1.33 KW	2.06 KW	5.0 KW
Capacitive KVAR Per Phase	1.0 KVAR	1.0 KVAR	1.0 KVAR	1.0 KVAR	1.0 KVAR	0 KVAR
Balanced 3Ø Load	3.46 KVA	3.75 KVA	4.2 KVA	5.0 KVA	6.88 KVA	15 KVA
Power Factor	0.5	0.6	0.7	0.8	0.9	1.0
V _{L-N} (nominal)	120 VRMS	120 VRMS	120 VRMS	120 VRMS	120 VRMS	120 VRMS
V+ to Common						
V- to Common						
I+ / I-						
V _{A-N}						
V _{B-N}						
V _{C-N}						
THD						
I _A / I _B / I _C						

Note Total harmonic distortion shall be less than 4%.

CODE IDENT NO	DWG SIZE	40M2 2460
	A	SHEET 20

ORIGINAL PAGE IS
OF POOR QUALITY

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

-Table V. Low Input Voltage Tests.

Input, Voltage	± 115 VDC		± 90 VDC	
Power factor	1.0	0.6	1.0	0.6
Balanced 3 ϕ Load	15 KVA	15 KVA	15 KVA	15 KVA
V+ to Com				
V- to Com				
V _{AN}				
V _{BN}				
V _{CN}				
I _{L+}				
I _{L-}				
I _A				
I _B				
I _C / I _N	/	/	/	/
THD				

CODE
IDENT NODWG
SIZE

40M22460

A

SHEET 21

REVISIONS

SYM	DESCRIPTION	DATE	APPROVAL
-----	-------------	------	----------

Table VI. Rectifier Load Tests.

	Half Wave	Full Wave	Transformer Rectifier
V_+ to Com			
V_- to Com			
I_+			
I_-			
I_A			
I_B			
I_C / I_N			
V_{out} DC			
I_{out} DC			
Output Ripple			
V_A / THD			

Note Output ripple shall be measured with an oscilloscope
(Tektronix Type 549 or equivalent)

CODE IDENT NO	DWG SIZE A	40M22460
		SHEET 22

ORIGINAL PAGE IS
OF POOR QUALITY


APPROVAL


EVALUATION OF A HIGH POWER INVERTER FOR POTENTIAL SPACE APPLICATIONS


By Buddy V. Guynes and John R. Lanier, Jr.

The information in this report has been reviewed for security classification. The report, in its entirety, has been determined to be unclassified and contains no information concerning Department of Defense or Atomic Energy Commission programs.

This document has also been reviewed and approved for technical accuracy.


for JIMMY L. MILLER
Chief, Power Branch


ROBERT M. ADEN
Chief, Electrical Division


F. BROOKS MOORE
Director, Electronics and Control Laboratory

DISTRIBUTION

INTERNAL

PD01 Mr. C. R. Darwin	EC12 Buddy V. Guynes (5) John R. Lanier, Jr. (5)	Johnson Space Center Houston, TX 77058 Attn: Mr. W. Stagg, Code EG2 Mr. R. Ferguson, Code EP
PD14 R. Boehme	EE41 J. W. Thomas	USAF (SAMSO) El Segundo, CA Attn: Cpt. D. Egan, Code DYV
EA01 J. E. Kingsbury W. Haeussermann	CC L. D. Wofford, Jr.	Griffiss Air Force Base New York, NY 13442 Attn: Mr. J. Collins, Code RADC/TUSS
DD01 R. G. Smith	AS61 (2)	
JA01 O. C. Jean	AS61L (8)	
NA01 T. J. Lee	AT01	General Motors Corporation Santa Barbara Operations 6767 Hollister Avenue Goleta, CA 93017 Attn: Mr. John Britt
SA01 R. E. Lindstrom	<u>EXTERNAL</u>	
FA01 C. K. Zoller	NASA Scientific and Technical Information Facility (25) P.O. Box 8757 Baltimore/Washington International Airport Baltimore, MD 21240	Jet Propulsion Laboratory 4800 Oak Grove Drive Pasadena, CA Attn: Mr. T. Williams, Code 198-220 Mr. D. Runkle, Code 198-220
ER01 J. B. Dozier	Goddard Space Flight Center Greenbelt, MD 20771 Attn: Mr. E. Rodriguez, Code 711.3 Mr. C. MacKenzie, Code 711.0	
EC01 F. B. Moore	Lewis Research Center 21000 Brookpark Road Cleveland, OH 44135	
EC11 R. M. Aden	Attn: Mr. J. Been, Code 54-1 Mr. H. W. Plohr, Code 3300 Mr. P. A. Thollot, Code 54-4	
EC12 J. L. Miller		